



POT AND PAN SOAP

POT AND PAN SOAP is a multi-purpose, neutral, non-corrosive and 100% biodegradable liquid detergent. To be used for manual dishwashing, soaking greasy pots and pans, cleaning venetian blinds and general purpose cleaning.

BENEFITS:

- Can be used on all surfaces, not harmed by water.
- Produces copious, dense foam that traps away grease, dirt and grime from dishes, pots and pans.
- Excellent rinsing properties.

PHYSICAL & CHEMICAL PROPERTIES:

- pH: 8.5
- Appearance: Clear, viscous, pink liquid
- Specific Gravity: 1.02

USE:

- **Hard Crusted, Hard Surface Area:** Use undiluted. Apply a small amount directly to stubborn area. Allow to stand until soil is loosened. Wipe off, rinse and wipe with a clean damp cloth.
- **Pots, Pans, Dishes:** Use 6mL/litre hot water. Soak several minutes, wash and rinse.
- **Venetian Blinds, Painted Walls, Woodwork, Windows, Countertops, etc.:** Use 3-6mL/litre water. Wipe with a cloth wrung out in a solution. Rinse and wipe with a clean damp cloth.

PRECAUTIONS:

- On surfaces subject to direct food contact, rinse thoroughly with potable water until foaming ceases.

PACKAGING:

- 4 x 4 L/Case
- 20 L Pail